

USE AND MAINTENANCE MANUAL

sesino
HEAT EXCHANGING EXCELLENCE SINCE 1919

**SHELL AND TUBE HEAT EXCHANGER WITH INSPECTABLE
AND WITHDRAWABLE TUBE BUNDLE FOR WATER-OIL**



MSG 84 & MSG 134 SERIES

INDEX

1.	INTRODUCING	3
2.	WARNING	3
2.1	Identification label	4
3.	TECHNICAL SPECIFICATIONS	5
4.	INSTALLATION	7
5.	PERIODIC MAINTENANCE	9
5.1	Internal cleaning	9
5.1.1	Shell side cleaning	9
5.1.2	Tube side cleaning	10
5.2	Zinc anode inspection and replacement	10
5.3	Cover removal	11
5.4	Tube bundle withdrawal	13
6.	SPARE PARTS AND INTERNAL COMPONENTS	15
7.	TAMPERING	20
8.	STORAGE	20
9.	WASTE DISPOSAL	20

**USE AND
MAINTENANCE
MANUAL**

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

1. INTRODUCTION

This manual must be considered an integral part of the heat exchanger and must be stored together with it throughout the exchanger's useful life.

Read the manual carefully before installing the heat exchanger.
The manual contains important safety information.

2. WARNING



a) The heat exchanger should only be intended for the use for which it was designed. Any other use could cause damage to property and people and therefore the manufacturer disclaims all responsibility for accidents arising from its misuse.



b) The exchanger shall be used for operating conditions (pressures and temperatures) and for fluids for which it has been calculated both thermally and mechanically and for which chemical compatibility has been assessed (see par. 3). In case of operating conditions other than calculation conditions, the performance of the exchanger changes and it is possible to even cause very serious damage to the device.



c) Fluid pressures and flow rates must be within design limits to avoid vibration, erosion and in some cases breakage of parts most affected by the dynamic action of fluids.



d) Before connecting the oil side and cooling water side feeds, verify that the hydraulic circuit complies with the performance of the heat exchanger.

USE AND MAINTENANCE MANUAL

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**



e) Do not touch the heat exchanger while operating. During exercise some external surfaces of the same may be very hot.



f) Do not remove the identification label (see par. 2.1) of the heat exchanger. On it are reported the technical data of the product and the contractual references that allow the traceability of the same. It is considered an integral part of the exchanger and must remain clearly visible on the same.

The manufacturer disclaims all liability for any damage to property and people due to non-compliance with these instructions or misuse or modifications made by unauthorized personnel.

2.1 IDENTIFICATION LABEL

Each heat exchanger is provided with an adhesive identification label. It shows the manufacturer, the model type, the number of internal baffles, the unique serial number of the heat exchanger, the design pressure (relative), the hydrostatic test pressure (relative) (they are both for the tube and shell side), the thermal heat exchanged in 4 configurations at different flow rate.

MADE IN ITALY		sesino	
TYPE	MSG 84 P1		nd. 3
oil flow l/min	30	80	N. 2100522
water flow	7.5 30	7.5 30	max bar oil 12
power kW $\Delta T_m 25^\circ C$	2 2.6	3 4.2	test press.bar 18
www.sesino.com - info@sesino.com			

MADE IN ITALY		sesino	
TYPE	MSG 134 P1		nd. 5
oil flow l/min	30	100	N. 2100544
water flow	15 60	15 60	max bar oil 12
power kW $\Delta T_m 25^\circ C$	4 4	9 12	test press.bar 18
www.sesino.com - info@sesino.com			

Figura 1: esempio di targa dati identificativa MSG

USE AND MAINTENANCE MANUAL

Shell and tube heat exchanger with withdrawable tube bundle for water-oil series **MSG**

3. TECHNICAL SPECIFICATIONS

The MSG series heat exchanger is a shell and tube type of heat exchanger. It has a withdrawable tube bundle. It is designed for heat exchange between water and oil (or similar) fluids. It has 4 passes on the tube-side. Its working principle is represented in the following figure.




Figure 2: MSG heat exchanger working principle

The following are the main features of operation:

- Hot fluid max. input temperature: **120°C**
- Cold fluid max. input temperature: **70°C**
- Operating fluids: **Mineral oil, Synthetic oil, Water Emulsified water, Glycol water**
- Maximum operating pressure: **12 bar**

Please note: contact our technical office in case of special applications.

USE AND MAINTENANCE MANUAL

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

When the final application machine, in which the heat exchanger is installed, is running at full speed, it is necessary to check that the right flow rate of water circulates in the heat exchanger. This can be done easily by controlling its thermal increase which should not be too low (too high flow rate), nor too high (low flow rate).

It is a good rule to consider a thermal increase of 10 °C when the temperature of the incoming water is 20 °C and a thermal increase of 5 °C with higher water temperatures. Usually the flow rate of water varies from about half that of the oil to the flow rate of the oil, depending on the temperature you want to obtain at the exit. To increase the heat dissipated by the exchanger, you can increase the flow rate of cold water.

It is also advisable to prevent the water speed from being too slow inside the heat exchanger because, when its temperature exceeds 50 °C, the limescale contained in it begins to settle appreciably reducing the section available inside the tube sections. In order to avoid erosive phenomena, however, the water speed must not be too high. As a reference, the optimal water speed is around 2.5 m/s (corresponding to a flow rate of 45 LPM for MSG 84 and 125 LPM for MSG 134).

If these values affect the heat exchange, contact our Technical Office for a thermodynamic verification of the final application.

It is possible that in hydraulic circuits there may be sudden pressure peaks (water hammer) that could approach or exceed the maximum permissible pressure from the exchanger, resulting in fluid leaks. These pressure changes are very rapid and are therefore not detected by common pressure gauges, which can only measure static pressure, but not dynamic pressures; In addition, the over-pressure valves are not even able to reveal such pressure changes. If it is not possible to contain this phenomenon, it is considered appropriate to feed the heat exchanger decoupled from the hydraulic network source of these disturbances, by means of a dedicated circuit with an autonomous recirculation pump.

**USE AND
MAINTENANCE
MANUAL**

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

4. INSTALLATION

Water-oil heat exchangers are generally installed in the return circuit.

It is also possible to make a separate circuit with an autonomous pump and this is advisable in case the oil flow rates at the discharge are very variable. This results in an improvement in thermal efficiency.

The connection of the water and oil fittings must be carried out in such a way that the air can be easily ejected with the normal circulation of fluids.

This means that if the exchanger is installed in a horizontal position (see Figure 2, Figure 3) up, while, if installed upright, the water fittings must be at the top and the oil must enter the fitting as low as possible.

Make sure that the exchanger is installed through its support feet (see Table 1 pos. 6) on a suitable support structure to withstand its weight, through the 4 anchor points provided as indicated in the general design of the heat exchanger (the weights and measurements of each model are shown in the catalog).

Warning: do not leave the exchanger suspended or fixed only through the inlet and outlet fittings of the heat exchanger, since hydraulic vibrations can break them; always ensure that the heat exchanger is fixed using its own installation support feet (pos. 6) at the 4 expected anchor points.

Warning: in case valves, heavy pipes or other hydraulic components are present on the circuit near the exchanger fittings, always ensure that their weight is supported independently of the heat exchanger, since vibrations can damage the inlet and outlet fittings; the exchanger is not suitable to support suspended masses of the hydraulic circuit whose weight must be supported regardless of the exchanger.

Warning: do not couple to the input and output connections of the heat exchanger (which have cylindrical (or parallel, ISO 228-1, G) female thread), other types of different thread; in particular do not insert connectors with male conical gas thread (or taper thread ISO 7, EN 10226, R), since the cylindrical female aluminium fittings of the exchanger can easily be damaged by screwing a conical male steel connector, with a minimum tightening torque and may no longer guarantee the seal because of permanent deformation or breakage of the aluminium female thread.

USE AND MAINTENANCE MANUAL

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

The inlet and outlet fluids should normally be connected to the heat exchanger as shown in the following figures:




Figure 3: MSG 84 installation




Figure 4: MSG 134 installation

USE AND MAINTENANCE MANUAL

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

5. PERIODIC MAINTENANCE

5.1. Internal cleaning

Depending on the needs and type of final application it is always good practice to check the heat exchanger at regular intervals of operation to prevent the limescale from completely filling internally the pipes or from corrosive deposits on the thermal exchange surfaces of the internal tubes, which compromise their efficiency.

You can internally clean the exchanger in several ways. The exchanger does not necessarily have to be disassembled. In fact, it is always possible to do an easier cleaning by circulating a cleaning product or solvent suitable for the type of fouling and the type of fluid, for a time that can vary from 10 to 30 minutes, even alternating the sense of flow.

In the case of low clogging due to limestone, it is advisable to circulate, in the opposite direction to the normal flow, a solution of 15% hydrochloric acid in water, or other similar fluids available on the market.

Alternatively, for more effective mechanical cleaning, it is recommended to proceed as follows in the following paragraphs.

Warning: during these operations, Costante Sesino S.p.A. recommends compliance with anti-pollution regulations and to use the appropriate services for the collection and disposal of spent oils and all contaminated water.

Warning: You need to be very careful when using chemical cleaning fluids. Carefully follow the supplier's instructions and use skin and eye protection systems. When expected to use a respirator.

5.1.1. Shell side cleaning

For more effective cleaning on the shell side, brushes or jets of water / steam under pressure should be used, after extracting the tube bundle (pos. 1). To withdraw the tube bundle, follow the indications in par. 5.4 .

Special care must of course be taken in manipulating the tube bundle so as not to damage the tubes and to provide adequate supports to avoid bending along the long tube bundles.

USE AND MAINTENANCE MANUAL

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

5.1.2. Tube side cleaning

For the inspection of the corrosion status and cleaning of the heat exchanger on the tube side, it is necessary to remove both covers (follow par. 5.3); it is not necessary to withdraw the tube bundle. For cleaning internally the tubes, brushes can be used and inserted inside the tubes, the internal diameter of which is 5.5mm.

Before remounting the covers, it is necessary to check that the zinc anode (pos. 12) is intact and clean; otherwise, it cannot perform its corrosion protection function and it shall be replaced (see para. 5.2). If the zinc anode is consumed in a short time, it is essential to check the efficiency of the grounding of the machine on which the exchanger is installed, because the presence of stray currents could cause corrosive phenomena too.

5.2. Zinc anode inspection and replacement

The sacrificial zinc anode (pos. 12) is placed within the water circuit on the tube side, with the function of protecting the materials from corrosion, by cathode protection with galvanic coupling of the less noble zinc metal, which acting as an anode, corrodes instead of the other metals of the heat exchanger.

Periodically the zinc anode should be inspected, to check the state of wear. If the anode is covered with a white layer of oxide (or even missing because it is completely corroded), it must be replaced, since the oxide acts as an electrical insulation, inhibiting the protective function of the anode. To inspect the zinc anode, you can remove the zinc anode plug from the cover (pos. 12), using a tool. The zinc anode is locked inside the plug by interference fixation on its diameter. For its replacement, remove it from the plug and insert a new one of the same diameter (MSG 84: 9, MSG 134: 10.4), always by interference fixation.

Warning: Before removing the zinc anode, make sure that the water circuit is not under pressure.

**USE AND
MAINTENANCE
MANUAL**

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

5.3 Cover removal

Below is the procedure for removing the head cover (pos. 4) or bottom cover (pos. 5):

1. Only for head removal (pos. 4) remove incoming and outgoing water fittings.
2. Unscrew the fixing bolts to the ground on the supporting feet (pos. 6).
3. Unscrew and remove M8 nuts (pos. 14).
4. Remove the supporting feet (pos. 6).
5. Remove the cover (pos. 4, 5).
6. Remove the O-Ring (pos. 8) which shall be always replaced before the cover is reassembled.

To keep the manifold stationary and the shell intact during cleaning operations, the manifold can be blocked by retightening the M8 nuts (pos 14) on the tie rods (pos. 7), without the covers.

Warning: before removing the cover, ensure that the water and oil circuits are not under pressure, because the oring (pos. 8) is the internal seal on both sides of the exchanger.

Warning: do not attempt to open or disassemble the exchanger head without the unit having been depressurized, drained and cooled until it is brought to room temperature.

Warning: do not remove the tie rods (pos. 7), nor the manifolds (pos. 3). You can lock the manifold by retightening the nuts on the tie rods without the covers.

Warning: do not rotate on its concentric axis the tube bundle (pos. 1).

**USE AND
MAINTENANCE
MANUAL**

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

To reassemble the cover proceed in the opposite direction, taking care to replace the O-Ring (pos. 8) with a new one. After bringing all the nuts to the cover surface, apply the tightening torque of about 12Nm evenly diagonally (see example below Figure 4 and Figure 5) without over tightening.




Figure 5: MSG 84 tightening sequence.




Figure 6: MSG 134 tightening sequence.

Warning: always replace the O-Rings (pos. 8) with new ones before remounting the cover. For MSG 84: OR 4300 NBR (234) 75.8x 3.53; for MSG 134: OR 4487 NBR (249) 123.4x 3.53.

Warning: the gaskets on the partition plate of the cover (pos. 10, 11) should be replaced if worn (silicone paste can also be used). Without replacement of these gaskets, there is not any leak, but there may be a slight decrease in the thermal power exchanged by the exchanger.

Warning: zinc anodes (pos. 12) mounted on covers should always be replaced if worn (see par. 5.2). After removing the covers, it is not necessary to disassemble the zinc anodes from the covers, for their inspection.

USE AND MAINTENANCE MANUAL

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

5.4. Tube bundle withdrawal

After removing both covers (following the procedure previously detailed in par. 5.3), it is possible to withdraw the tube bundle (pos. 1), which is no longer constrained by the cover, by applying an axial force on it. There is no need to remove oil fittings from the shell. Be careful not to move the manifolds. Follow the steps:

1. Remove a cover.
2. Remove the other cover.
3. Secure the manifolds by screwing the nuts on the tie rods without covers, so that it remains stationary during the extraction of the tube bundle. It is also possible to re-fixate the heat exchanger on the ground frame using the support feet (pos. 6) by remounting them without the covers, in case it is not possible to hold the exchanger blocked in another way.
4. Gently withdraw the tube bundle without damaging any internal components.

Warning: before removing the tube bundle make sure that the water and oil circuit is not under pressure.

Warning: after the withdrawal of the tube bundle, handle it very carefully, avoiding damaging it in all its part; in particular pay attention to the circumferential outer surface of the tubesheet, which does the pressure seal on the oring.

**USE AND
MAINTENANCE
MANUAL**

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

To reinsert the tube bundle inside the heat exchanger, proceed in the opposite direction.

Warning: after reinserting the tube bundle, before remounting the cover, check that the indication mark on the front side tubesheet is vertically aligned with the vertical indication mark on the front side manifold, as in the following figures:




Figure 7: MSG 84 vertical alignment indication marks on tube bundle / manifold.




Figure 8: MSG 134 front view vertical alignment indication marks on tube bundle / manifold.

**USE AND
MAINTENANCE
MANUAL**

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

6. SPARE PARTS AND INTERNAL COMPONENTS

Below is the internal scheme of the heat exchanger with the list of internal components of which it is composed. For any request of spare parts provide the model name on the identification label (see par. 2.1) and the denomination (see Table 1).

Figure 9: MSG 84 exploded view




Figure 10: MSG 84 exploded view

Rif.	Descrizione
1	Tube bundle
2	Shell
3	Manifold
4	Head
5	Rear
6	Support foot
7	Tie rod
8	Oring
9	Shell manifold gasket
10	Head passpartition gasket
11	Rear passpartition gasket
12	Plug with zinc anode
13	Washer
14	M8 nut

Table 1: Internal component list

**USE AND
MAINTENANCE
MANUAL**

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

p. 15




Figure 11: MSG 84 internal section

Rif.	Descrizione
1	Tube bundle
2	Shell
3	Manifold
4	Head
5	Rear
6	Support foot
7	Tie rod
8	Oring
9	Shell manifold gasket
10	Head passpartition gasket
11	Rear passpartition gasket
12	Plug with zinc anode
13	Washer
14	M8 nut

Table 1: Internal component list

USE AND MAINTENANCE MANUAL

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**




Figure 12: MSG 134 internal section

Rif.	Descrizione
1	Tube bundle
2	Shell
3	Manifold
4	Head
5	Rear
6	Support foot
7	Tie rod
8	Oring
9	Shell manifold gasket
10	Head passpartition gasket
11	Rear passpartition gasket
12	Plug with zinc anode
13	Washer
14	M8 nut

Table 1: Internal component list

USE AND MAINTENANCE MANUAL

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

In the following figures the exploded view at the front side:

Figure 13: MSG 84 exploded view front side




Figure 14: MSG 134 exploded view front side

Rif.	Descrizione
1	Tube bundle
2	Shell
3	Manifold
4	Head
5	Rear
6	Support foot
7	Tie rod
8	Oring
9	Shell manifold gasket
10	Head passpartition gasket
11	Rear passpartition gasket
12	Plug with zinc anode
13	Washer
14	M8 nut

Table 1: Internal component list

**USE AND
MAINTENANCE
MANUAL**

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

In the following figures the exploded view at the rear side:

Figure 15: MSG 84 exploded view rear side




Figure 16: MSG 134 exploded view rear side

Rif.	Descrizione
1	Tube bundle
2	Shell
3	Manifold
4	Head
5	Rear
6	Support foot
7	Tie rod
8	Oring
9	Shell manifold gasket
10	Head passpartition gasket
11	Rear passpartition gasket
12	Plug with zinc anode
13	Washer
14	M8 nut

Table 1: Internal component list

USE AND
MAINTENANCE
MANUAL

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

7. TAMPERING

Any operation to modify the heat exchanger, carried out without prior authorization of Costante Sesino S.p.A., will automatically result in the decay of the warranty clauses.

8. STORAGE

The heat exchanger must be stored in a moisture-free environment (HR < 60%) and at a temperature (-10 °C to 40°C), such as to avoid condensation and oxidation to the internal parts of the same. The heat exchanger can be stored indefinitely in an internal environment.

Warning: Avoid subjecting the heat exchanger or any of its internal components during storage to ambient thermal cycles.


9. WASTE DISPOSAL

The heat exchangers of Costante Sesino S.p.A. are built with entirely recyclable materials. Disposal can take place in compliance with the environment according to local legal requirements in the local area of use. During maintenance, spent lubricating oil must be disposed of correctly.


USE AND MAINTENANCE MANUAL

Shell and tube heat
exchanger with
withdrawable tube
bundle for water-oil
series **MSG**

MSG 84



MSG 134



Quality Management System



Occupational Health and
Safety Assessment Series

COSTANTE SESINO SPA:

via Monza, 150 A/B 20060 GESSATE (MI)

info@sesino.com - www.sesino.com

tel. +39 02.95.38.03.34 - fax +39 02.95.78.05.28